



Maintenance

Suggested Fabric Care & Maintenance

Air pollution, smog, and/or other kinds of particles may be deposited on Tempotest fabrics. Oftentimes, dirt of this nature can be removed by simply brushing the surface of the fabric with a soft brush and then spraying it with clean warm water (not to exceed 100°F) and allowing it to air dry.

Periodically, the fabric should undergo a deeper cleaning. Avoid the use of detergents, use only mild soaps like Woolite® or Ivory® soap.

Gently brush the surface of the fabric with a solution of clean warm water and nondetergent soap (2 ounces of mild soap in a gallon of water not hotter than 100°F) and allow to sit for 15 minutes.

Then rinse thoroughly to completely remove the soap and allow the fabric to dry completely in the open-air.

Some locations may lead to tougher stains. Tree resin or sap may be transferred to the fabric or mold can grow in areas where water pocket are present. In these situations, it is recommended to follow the procedure above and add bleach to the solution, diluted at a ratio of 1:16 per gallon of clean warm water (no hotter than 100 F).

Do not iron Tempotest fabrics with steam and do not dry by using electrical devices. During the winter season it is advisable to store the fabric in a dry and well-ventilated environment.

